TABLE OF CONTENTS

Chapter 1: Introduction

Introduction 1-2

The Purpose of this Manual 1-2

Who Can and Should Use DirectSOFT 6 1-2

Only One DirectSOFT 6 Version 1-3

Supplemental Manuals 1-4

Technical Support 1-4

Conventions Used 1-5

Menu Selections and Keystrokes 1-5

Key Topics for Each Chapter 1-5

Chapter 2: Quick Start

Getting to Know Windows 2-2

Recommended System Requirements 2-2

Power Supply 2-2

***Direct*SOFT 6 Package Contents 2-2**

Installation of *Direct*SOFT 6 2-3

Getting Started 2-8

Welcome to *Direct*SOFT 100 2-12

Begin Editing a Program 2-14

Establish the Communication Link 2-24
Connect the PC to the PLC 2-24

Monitor the Program 2-30

Chapter 3: Managing Projects

Get Started Using *Direct*SOFT 6 3-2
Understanding the Launch Window 3-2

Create a New Project 3-4
New Program 3-4
Enter the New Project Information 3-4

Importing Projects 3-5
Program Documentation Mapping from TISOFT and Logicmaster 3-6

Copy or Save Existing *Direct*SOFT Files 3-7

Chapter 4: Programming Environment

Offline Toolbar Components 4-2
Offline Toolbar 4-2

Online Toolbar Components 4-5
Online Toolbar 4-5

Additional Toolbars 4-6
The File Toolbar 4-7
The Edit Toolbar 4-8
The Search Toolbar 4-9
The View Toolbar 4-10
The Tools Toolbar 4-11
The PLC Toolbar 4-12
The PLC Diagnostics Toolbar 4-13
The PLC Setup Toolbar 4-13
The Debug Toolbar 4-15
The Window Toolbar 4-16

The Help Toolbar 4-17
The Custom Toolbar 4-17

Status Bar Components 4-19
PLC System Information 4-19
Communication/Link Information 4-20
PLC Mode 4-20
Program Memory Usage 4-20
PLC Type 4-20
Program Location 4-20

The Options Dialog 4-21
Ladder Options 4-22
Global Options 4-23

Colors in *Direct*SOFT 6 4-24
Select New Colors 4-24
Color Selections 4-25
The Default Settings 4-25
Monochrome 4-25
Colors Conveying Information 4-26
Select a Theme 4-27

The Ladder Palette 4-28
Be Familiar with the Ladder Palette 4-28

The Split Screen Feature 4-30
Split Screen Bar 4-30

The New Window Feature 4-31

Chapter 5: Edit a Program

I/O Configuration 5-2

Referencing Program Elements 5-4
Data Types 5-4
Aliases 5-5
Timer/Counter Current Values 5-5

Accessing I/O Points as Memory Locations 5-5

Entering Program Instructions 5-6

The Instruction Editor 5-6

Using the Ladder Palette 5-8

Opening the Instruction Browser 5-8

Shortcuts for Entering Instructions 5-11

Entering NO and NC Contacts 5-12

Entering Instructions in Parallel 5-13

Entering Power Flow Instructions 5-14

Entering Special Case Elements 5-16

End Coil 5-17

Setting and Resetting a Bit 5-18

Using Floating Point Math 5-18

Drawing/Deleting Connecting Lines 5-19

Drawing the Lines 5-19

Create Midline Outputs 5-20

Deleting Connecting Lines 5-20

Selecting Rungs for Deleting, Cutting or Copying 5-21

Deleting Rungs 5-22

Copying Rungs 5-23

Cut and Paste Rungs 5-25

Merge (Combine) Rungs 5-26

Inserting Columns, Rows and Rungs 5-27

Insert a Column to Add an Instruction 5-27

Insert a Row or Rung 5-28

Using Search and Replace 5-29

Using the Object Section 5-29

The Search Range Section 5-30

The Document Section 5-30

The Object Table Section 5-30

Common Mistakes 5-31

Failure to Enter the Edit Mode 5-31
AND above a Join 5-31
Forgetting to Select Rungs 5-31

Chapter 6: Documentation

Turn Documentation On and Off 6-2
The Options Dialog 6-2
Documentation Selections 6-3
General Documentation 6-3
Using the Documentation Editor 6-4
Using the Scroll Buttons 6-4
Copying Documentation Between Elements 6-5
Documenting and Assigning Nicknames 6-6
Create an Unassigned Nickname 6-6
Assign the Nickname to an Element 6-6
Entering Rung Comments 6-9
Comments are Free-form 6-9
Selecting Rungs for Comments 6-9
Using the Scroll Buttons 6-10
Use the Editing Keys 6-10
Move Rung Comments 6-11
Entering Stage Comments 6-12
Use Stage View 6-12
Comments are Free-form 6-13
Selecting Stages to Comment 6-13
Editing the Comments 6-13
Importing and Exporting 6-14
Exporting Program Documentation 6-14
Export Element Documentation 6-16
Export Rung Comments 6-18
Importing a Program 6-19

Importing Element Documentation 6-22
Importing Program Comments 6-24
Insert Instructions 6-24
Restore 6-27

Prevent Documentation Loss 6-28
Save Project 6-28
Backup Project 6-29

Chapter 7: Other Views

Tabbed Views 7-2
The Primary Views 7-2

Stage (RLL^{PLUS}) View 7-4
Troubleshooting RLL^{PLUS} vs. RLL 7-4
Stage Components 7-5

Mnemonic View 7-6
Handheld Progammer Aid 7-6

Cross Reference (XRef) View 7-7
XRef Mode 7-7
Change the XRef Query 7-8
XRef Toolbar 7-9
Usage Mode 7-10
Usage Mode Toolbar 7-10
XRef DB 7-11

PID View 7-12
PID Setup 7-12

Trend View 7-14
Creating a new Trend View 7-14

Output Window 7-16

Bookmark 7-18

View Terminology 7-19

Chapter 8: Printing

Print the Current View 8-2
Print the Ladder View 8-2
Other Print Views 8-3
Print Multiple Views 8-5
Print View Common Setup 8-7
Using Print Preview 8-8
Print Preview Setup 8-8
Print Preview 8-9
Print Troubleshooting 8-10
Parts of Program not Printed 8-10
Program Prints “Garbage” 8-10
*Direct*SOFT 6 Crashes 8-10
Print Setup Dialog 8-11

Chapter 9: Setup & Manage Communication Links

Establish the Communication Link 9-2
Setup a Serial Link 9-2
Link Status 9-6
Setup an Ethernet Link 9-7
NetEdit3 Troubleshooting Tips 9-12
Setup a Modem Link 9-14
Modem Setup 9-14
Configuring the Link 9-18
Comm Link Options 9-22
Going Online 9-24
Connect the PLC 9-24
Use the Project Folder 9-24

Use the Link 9-24

Chapter 10: Debugging and Monitoring

Monitor with Data View 10-2
Using Data View 10-2
Open a New Data View Window 10-2
A Closer Look 10-3
Data View Options 10-4
Select Bits for Display 10-5
Data View Documentation Options 10-7
Apply Options 10-7
Data View Mode Options 10-8
Make Data View Entries 10-8
Data Format and Size 10-10
Write the Edits 10-11
Auto-increment 10-12
Editing Entries 10-12
Save the Data View Window 10-13
Using Pause Bits 10-14
Use Override Bits to Control I/O (DL05/06/240/250-1/260/350/450 Only) 10-15
Change Value Dialog 10-16
Use the Change Value Dialog 10-16
Specify an Element Reference or Nickname 10-17
Enter a New Value 10-18
Using the Memory Editor 10-20
Select the Locations to View 10-20
Test Mode Operations for Debugging 10-22
Select Test Mode 10-22
Test Program Operations 10-23
The Test Operations Window 10-24
Trap Monitor 10-25

Access the Trap Monitor 10-25
Use with Data View 10-27

Stack Monitor (DL440 Only) 10-28
Access the Stack Monitor 10-28

Trend View 10-29
Using Trend View 10-29
The Crosshair Cursor 10-30

Check *Direct*SOFT 6 File Revision 10-33

Appendix A: Protocols and Cable Diagrams

Cables and Protocols A-2

Programming Cable Diagrams A-6

AppendixB: Communications Troubleshooting

Communications Resources B-2
Startup B-2
USB-TO-SERIAL Devices B-9
DUMP B-10

Editing the DSxxx.ini File B-10
Windows XP and Windows 7/8 . . . . . .B-10
Windows Vista B-11
UAC = ON B-11
UAC = OFF B-12
Other Editable Parameters B-12

Other Possible Issues B-15
How to Change USB-Serial Port Assignment B-15
“PORT UNAVAILABLE OR IN USE” B-15
Laptop AC Adapter Issue B-15

Notes: